Overview
Instrument Panel
Shift paddle switches (automatic transmission) P.16
Headlight switch P.28
Turn signal lever P.22
Fog light switch P.29
Multi-information display P.20
Headlight cleaner switch * P.32
Rear sunshade switch * P.46
Inside door lock button P.53
Fuel filler door opener P.55
Driving and seat position memory switches * P.11
Window lock switch P.54
Power window switches P.54
Door lock switches P.53
Outside rear view mirror switches P.13
Trunk opener P.56
Parking brake pedal (automatic transmission) P.19
Hood release lever P.55
Satellite switches P.21
Tilt and telescopic steering lock release lever * P.14
Tilt and telescopic steering control switch * P.14
CLYQFAB237

Shift paddle switches (automatic transmission) P.16
Windshield wipers and washer switch P.30
Engine (ignition) switch P.15
Air conditioning system P.39
Emergency flasher switch P.22
Rear window and outside rear view mirror defoggers P.32
Security indicator light P.8
Audio system P.33
Glove box P.45
Trunk opener main switch P.56
A
CLYQFAB394
See P.5.
ECT switch (automatic transmission) P.23
ETCS switch (manual transmission) P.23
Distance switch * P.26
Cruise control switch * P.25
Dynamic radar cruise control switch * P.26
* : If equipped

▶ Automatic transmission

▶ Manual transmission

* : If equipped